

Gaposa Motion Sensor QCMSZ

QUICK REFERENCE GUIDE




Attention: Motion sensor does not protect the awning against strong sudden wind gusts. Keep the awning closed if there is a risk of such meteorological event. Wind gust durations must be over 6 seconds to trigger awning to retract.



Always use the highest quality of battery due to the Arizona heat.

PRODUCT DIAGRAM



SENSITIVITY ADJUSTMENT

Adjust the sensitivity to determine how much motion is required to trigger the awning to retract.

1	= Awning only needs to move slightly to retract
4	= Basic factory setting
9	= Awning must vibrate strongly before retracting



TROUBLESHOOTING

Issue	Recommended Action
Awning retracts every 20 minutes	Replace batteries
Awning extends by forcing the opening	Replace batteries
Awning extends 4 inches and retracts	Motion sensor retracted awning; wait 20 minutes before awning can be extended
Awning retracts with very little wind	Increase potentiometer sensitivity
Awning does not retract in high winds	Decrease potentiometer sensitivity